


Removing the Camera's Privacy Screen from a Lenovo Computer

The camera light on my Lenovo computer is on, but when I connect to a session using Connectivity I do not see my picture on the screen. I only see an image with a gray background and a white camera with a cross through it, how can I fix this?



WINDOWS 8 and 10


1. Open the Windows start menu, and type '**Lenovo Settings**'. Click or tap to open.



2. Find the CAMERA icon along the top or side menu. Click or tap to open.



3. Near the bottom of the page you should see a section titled PRIVACY MODE



4. Turn Privacy Mode **Off** by clicking or tapping the button. You want it to be black, not blue.



WINDOWS 7

1. Open the Windows Start Menu and type '**Lenovo - Web Conferencing**' to search.
2. Once opened, start the camera and close the Lenovo - Web Conferencing application.